


EOM

ENGINEERING OPERATION
& MAINTENANCE


Wilden SafeGuard™

User Interface

www.wildensafeguard.com



Where Innovation Flows



CONTENTS

- Section 1: ACCOUNT SETUP 2
- Section 2: ICONS AND COLOR KEY 2
- Section 3: VIEWING CONNECTED PUMPS..... 2
- Section 4: DASHBOARD 2
- Section 5: CUSTOMIZATION..... 2
- Section 6: MAINTENANCE LOG 2
- Section 7: MOBILE APPLICATION 2

Copyright

Copyright 2020 PSG®, a Dover Company. All rights reserved.

PSG reserves the right to modify the information and illustrations in this document without prior notice. The product described in this document is furnished under a license agreement or nondisclosure agreement. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording, without the written permission of PSG, a Dover Company, except as described by the terms of those agreements.

This is a non-contractual document. 01-2020.

Trademarks

PSG and the PSG logo are registered trademarks of PSG. Wilden® is a registered trademark of PSG California LLC. SafeGuard™ is a trademark of PSG.

All trademarks, names, logos and service marks (collectively "trademarks") in this document are registered and unregistered trademarks of their respective owners. Nothing contained in this document should be construed as granting any license or right to use any trademark without the prior written permission of the trademark owner.

Data Security and Privacy Policy

The use of Wilden SafeGuard Remote Monitoring and Alert System requires agreement to Wilden's Privacy Policy, End User License Agreement, and Master SaaS Agreement. For copies of these policies, please visit www.psgdover.com/wilden/products/performance-monitoring-and-alert-system/wilden-safeguard


User Interface Updates

Please note that we are continuously updating the user interface in order to provide a better experience for our customers. The user interface may differ slightly from this instruction manual. If you have any questions or need assistance, please contact wildensafeguard@psgdover.com.



Account Setup

Wilden will assist with creating the initial account set up. For account setup, please reach out to wildensafeguard@psgdover.com. Once the account is set up, logins can be created to give access to other team members or admins.

1. Click on your name in the upper right-hand corner of the login screen and select “Users”.



2. Select the Account from the drop down of where the User will be created and Select “New” to create a new User.



3. Complete the User Details Form. Each User must have their own unique email address.

User Details

User Name *

First Name *

Last Name *

Primary Email *

Secondary Email

Mobile Phone

Fax

Comments

Approve Date

Language None ▾


Access Level User ▾

Logger Default Page Data View ▾

Enabled

4. Select Access Level
 - a. Account Admin
 - b. User

5. Click Save to create the user. An activation email will automatically be sent to the Primary Email address in the User Details Form.





To Edit an Existing User (Account Admin Access Level Only)

1. Click on your name in the upper right-hand corner of the screen and select “Users”
2. Click on the User you wish to make changes to
3. Click “Edit”
4. Edit the fields you wish to change (Note: You cannot change the Login Name)
5. Click “Save” to save the information and update the user

To Delete an Existing User (Account Admin Level Access Only)

1. Click on your name in the upper right-hand corner of the screen and select “Users”
2. Click on the User you wish to delete
3. Click “Delete”
4. Confirm in the pop-up box





Icons and Color Key



Wilden SafeGuard User Interface contains icons as well as colors to indicate equipment as well as their current status and condition. The following is a guide to what each icon and color identifies.

Gateway Node

A Gateway Node is identified by the following icons

-  Indicates a Gateway Node that is active and communicating with the servers
-  Indicates a Gateway Node that is inactive and NOT communicating with the servers

An Edge Device (a connected Pump) is identified by the following icons

-  Indicates an Edge Device (Pump) that is active and communicating with the servers
-  Indicates an Edge Device (Pump) that is inactive and NOT communicating with the servers

Color Indications

- In general, items that are colored “green” indicate that relevant item is on, active, or connected
- In general, items that are colored “blue” indicate that the relevant item is performing normal
- In general, items that are colored “orange” indicate a warning
- In general, items that are colored “red” indicate an alert

Viewing and Searching for connected Pumps and Gateway Nodes


There are multiple ways to search for, find, and select a Pump or a Gateway Node.

- From Tree
- From Fleet Overview – List
- From Fleet Overview – Map
- From Search

From Tree View

Upon login, on the left side of the main screen, click on the Main Account. From there, different account(s) under the main account will be listed. Select the account you want to view and all Pumps and Gateway Nodes assigned within that account will be listed.



Click on the desired Pump or Gateway Node to view.



From Fleet Overview – List View

As an alternative way to view and search for Pumps, upon login, click the Global View link and select List. From there, a full list of Pumps as well as Gateway Nodes will appear.

Click on the icon next to the desired Pump or Gateway Node to view.





The screenshot shows the "Pump Fleet Overview" page in "List" view. It features a search bar at the top right and a table with the following columns: DeviceID, Device Name, Dealer Name, Account Name, Last Comm, and Subscription. The table contains 17 rows of data, each with a status icon on the left.

| DeviceID | Device Name | Dealer Name | Account Name | Last Comm | Subscription |
|----------|------------------|-------------------|----------------|------------------------|--------------|
| 18 | PSD gateway (18) | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/02/2020 08:24:41 PM | Active |
| 19 | ADD0 stove (19) | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 05/12/2019 10:00:51 AM | Active |
| 230 | 230 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/02/2020 10:25:28 AM | Active |
| 231 | Testing UI | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 232 | 232 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 233 | 233 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 238 | 238 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 239 | 239 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 235 | 235 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 236 | 236 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 237 | 237 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 241 | 241 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |
| 903 | 903 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 01:08:14 PM | Active |
| 950 | 950 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 01/30/2020 12:03:53 PM | Active |
| 234 | 234 | PSD_WILDEN_DEALER | PSD_WILDEN_PDC | 04/10/2012 10:08:14 AM | Active |

From Search

To search for a Pump or Gateway Node by using the search functionality, use the search box in the upper right-hand corner of the screen. In this box you can enter the ID or name of the Pump or Gateway Node you are searching for.



Dashboard


Once you've selected the appropriate Pump you'd like to view, you are then taken to the Pump's Dashboard. From the Dashboard you can:

- View an overview of the Pump's current performance status
- View current stroke rate and stroke count
- View and set parameters of stroke warning and stroke fault
- View leak, stroke count threshold warning, and stroke count threshold fault indicators/alerts
- View operation history over time
- Reset count after failure addressed
- Review service/maintenance history
- Review relevant documents
- Review any relevant reports



Settings

If at any time you wish to edit the Pump or Gateway Device Settings such as Name, Main Account, Account, Time Zone, or Daylight Saving, click on “Service” and then “Device Settings”.

A dark-themed form with three buttons at the top: 'Save', 'Clear pending messages', and 'Get Cell Tower Position'. The form fields are: ID (dark grey), Name (text input), PSG_WILDEN_DEALER (dropdown), PSG_WILDEN_POC (dropdown), Time zone (dropdown with '(GMT-08:00) Pacific Time (US & Canada)'), Day Light Saving (dropdown with '60' and a 'Set Clock' button), Latitude (text input), and Longitude (text input). A trash icon is at the bottom right.

Customizing Parameters and Alerts

There are several opportunities to set up customized parameters and alerts based on your system requirements. You can customize the parameters and identify the users that receive alerts for:

- Pump Status (on or off)
- External Power (on or off) (Applicable to Tier 3 Models Only)
- Stroke Rate
- Leak Detection (Tier 2 Only)
- Stroke Count Warning
- Stroke Count Fault


To customize the alerts, click on the appropriate item on the Dashboard:



For Pump Status

If an Edge Device is triggered “On” or “Off” you can set up who will receive the alert, how they will receive it, the message they will receive, and who the alert will be escalated to if left unaddressed. To set the alerts click “Pump”. An Alert setup box will appear. The setup will allow you to determine which users and what text they should receive any time the Pump is On or triggered to Off.


To select users to receive alerts, click “Select Users”. From there, you can identify whether they receive an email (@1 for Primary Email and @2 for Secondary Email) and/or an SMS as well as identify the User the alert will get escalated to if the initial one is not addressed within 5 minutes. Click “Save” when complete. Then, back on the Alerts box, click “Ok” when done.



The Alerts dialog box has a title bar with "Alerts" and a close button. It contains a table with two columns: "Properties" and "Edit".

| Properties | Edit |
|-----------------------|--------------|
| Condition set alert | Select Users |
| Alert text | Pump ON |
| Condition reset alert | Select Users |
| Alert text | Pump OFF |

At the bottom right, there are "Ok" and "Cancel" buttons.



The Select Users dialog box has a title bar with "Select Users". It contains a table with columns for user selection and escalation options.

| User | @ 1 | @ 2 | SMS | Escalation 1 | Escalation 2 |
|--------|--------------------------|--------------------------|--------------------------|--------------|--------------|
| User 1 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 2 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 3 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 4 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 5 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 6 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 7 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |

At the bottom right, there are "Save" and "Cancel" buttons.

For External Power (Applicable to Tier 3 Models Only)

External Power is set up exactly the same way as Pump Status. To set the alerts to notify users if the External Power is On or Off, click “External Power”. An Alert setup box will appear. The setup will allow you to determine which users and what text they should receive any time the External Power is On or Off.

To select users to receive alerts, click “Select Users”. From there, you can identify whether they receive an email (@1 for Primary Email and @2 for Secondary Email) and/or an SMS as well as identify the User the alert will get escalated to if the initial one is not addressed within 5 minutes. Click “Save” when complete. Then, back on the Alerts box, click “Ok” when done.

The Alerts dialog box has a title bar with a close button (X). It contains two main sections: Properties and Edit. The Properties section has two rows: 'Condition set alert' and 'Condition reset alert'. The Edit section has two rows: 'Alert text' for 'Condition set alert' and 'Alert text' for 'Condition reset alert'. The 'Select Users' button in the Edit section is highlighted with a yellow box.

| Properties | Edit |
|-----------------------|--------------------|
| Condition set alert | Select Users |
| Alert text | External Power ON |
| Condition reset alert | Select Users |
| Alert text | External Power OFF |

Buttons: Ok, Cancel

The Select Users dialog box contains a table with columns for User, @1, @2, SMS, Escalation 1, and Escalation 2. There are 7 rows of users. The @1, @2, and SMS columns have checkboxes. The Escalation 1 and Escalation 2 columns have dropdown menus set to 'None'. There are Save and Cancel buttons at the bottom.

| User | @ 1 | @ 2 | SMS | Escalation 1 | Escalation 2 |
|--------|--------------------------|--------------------------|--------------------------|--------------|--------------|
| User 1 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 2 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 3 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 4 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 5 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 6 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |
| User 7 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None | None |

Buttons: Save, Cancel

For Leak Detection, Stroke Count Warning, and Stroke Count Fault

The Stroke Count Warning and Fault Limits can be customized to your system requirements and can be set right from your Pump dashboard. Enter the limits (number of strokes) in the value box and click the “Save” icon. It’s recommended to set the Threshold Warning Level at 80% of the value of your Threshold Fault. For Example: If your Threshold Fault is 1,000 Strokes, we would recommend you set your Threshold Warning at 800 Strokes.

The screenshot shows the Wilden Pump Dashboard interface. At the top, there is a navigation bar with 'Main', 'Reports', 'Service', and 'Documents'. Below this, a breadcrumb trail reads 'Main > Items Menu > Dashboard > 331(330)'. A status bar indicates 'Last update 03/18/2020 03:01:47 PM'. A 'Get Status' button is prominently displayed.

The main dashboard area is divided into several sections:

- Control Panel:** Includes 'Pump ON' (checked) and 'External Power' (unchecked) indicators.
- Stroke Rate Gauge:** A circular gauge showing a current stroke rate of 50.
- Alerts:** Three checkboxes for 'Leak', 'Stroke Count Threshold Warning', and 'Stroke Count Threshold Fault', all currently unchecked.
- Configuration Table:** A table with three columns: 'Parameter', 'Value', and 'Save'. The 'Save' column contains save icons. The 'Strokes Warning' and 'Strokes Fault' rows are highlighted with a yellow border.

| Parameter | Value | Save |
|-----------------|-------|-------------|
| Stroke Count | 5591 | [Save Icon] |
| Strokes Warning | 6000 | [Save Icon] |
| Strokes Fault | 8000 | [Save Icon] |
- Filtering and Refresh:** Fields for 'Start Date' (03/11/2020) and 'End Date' (03/18/2020), along with 'Lower' and 'Upper' range settings (both 0). There are checkboxes for 'Show Points' and 'Show Boundaries', and a 'Refresh' button.
- Stroke Rate Graph:** A line graph titled 'Stroke Rate' showing data from 11. Mar to 18. Mar. The y-axis ranges from 0 to 10. The graph shows a flat line at 0 until approximately 12.5 Mar, where it spikes to 5, and then returns to 0. A legend at the bottom identifies the line as 'Stroke Rate'.

Whether a Leak, Stroke Count Threshold Warning or Threshold Fault is identified, you can set up users to receive the alert, how they receive it, the message received and the escalation users if the alert is not addressed. To set each alert, click the item you want to set, for example, click “Leak”. An Alert box will appear. The setup will allow you to determine which users and what text they should receive any time a Leak is detected or cleared.

To select users to receive alerts, click “Select Users”. From there, you can identify whether they receive an email (@1 for Primary Email and @2 for Secondary Email) and/or an SMS as well as identify the User the alert will get escalated to if the initial one is not addressed within 5 minutes. Click “Save” when complete. Then, back on the Alerts box, click “Ok” when done.

Alerts ✕

| Properties | Edit |
|-----------------------|------------------------------------------------------------------------------------------|
| Condition set alert | Select Users |
| Alert text | Leak Detected |
| Condition reset alert | Select Users |
| Alert text | Leak Cleared |

Ok
Cancel

Select Users

| User | @ 1 | @ 2 | SMS | Escalation 1 | Escalation 2 |
|--------|--------------------------|--------------------------|--------------------------|--------------|--------------|
| User 1 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 2 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 3 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 4 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 5 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 6 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 7 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |

Save
Cancel

For Stroke Rate

When it comes to Stroke Rate, you're able to customize the minimum threshold and the maximum threshold required for your system that would require an Alert. To set these thresholds, click "Stroke Rate". A Gauge Alert window will pop up. From there, indicate the number of strokes you require as the Minimum Threshold and the Maximum Threshold. At the same time, you can also select the Users you wish to receive the Alert once a Minimum or Maximum Threshold is met as well as the message they will receive.

Additionally, you can customize to view the percentage threshold and the account.

Gauge Alerts ✕

| Properties | Edit |
|---------------------------|------------------------------------|
| Min.threshold | 15 Select Users |
| Min.threshold alert text | Stroke Rate Low |
| Max.threshold | 50 Select Users |
| Max.threshold alert text | Stroke Rate High |
| Show precentage threshold | <input type="checkbox"/> |
| Account | ▼ |

[Ok](#) [Cancel](#)

Gauge Alerts ✕

| Properties | Edit |
|---------------------------|------------------------------------|
| Min.threshold | 15 Select Users |
| Min.threshold alert text | Stroke Rate Low |
| Max.threshold | 50 Select Users |
| Max.threshold alert text | Stroke Rate High |
| Show precentage threshold | <input type="checkbox"/> |
| Account | ▼ |

[Ok](#) [Cancel](#)

Select Users


| User | @ 1 | @ 2 | SMS | Escalation 1 | Escalation 2 |
|--------|--------------------------|--------------------------|--------------------------|--------------|--------------|
| User 1 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 2 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 3 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 4 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 5 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 6 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |
| User 7 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | None ▼ | None ▼ |

[Save](#) [Cancel](#)


Click "Save" when complete. Then, back on the Gauge Alerts box, click "Ok" when done.

Maintenance Log

Another feature of the Wilden SafeGuard System is that it allows you to keep track of all service records of your pumps that are connected. To view, add, or edit a service record, click “Service” on the main Dashboard of the particular Edge Device or Gateway Node you are servicing. From the “Service” drop down menu, click “Service Records”.




From there, all the service records that have been reported on the selected Edge Device or Gateway Node will appear. To add a new service record, click the “Add” button.



| Time Stamp | Description | Edit | Delete |
|------------------|------------------------------------------------------------|------|--------|
| 03/16/20 12:10PM | Pump running as expected. Leak detection on pump is active | | |
| 03/16/20 12:09PM | Pump air valve changed | | |
| 03/16/20 12:09PM | Pump is back online. Diaphragms were changed on the pump | | |
| 03/16/20 12:08PM | Pump is taken offline for maintenance | | |
| 02/27/20 01:21PM | Pump Operational, Pump includes Wilden Safeguard | | |
| 01/29/20 03:08PM | Pump turned on for standard operation | | |

A window will pop up, allowing you to fill in the description of the new service record. Click “Save” when complete. The new service record will then be added to the records list.




Free Text Service ✕

Description


Save
Close

To Edit or Delete an existing Service Record, click the Edit or Delete icon next to the Service Record you wish to Edit or Delete. When editing, click “Save” when complete.



| Time Stamp | Description | Edit | Delete |
|------------------|------------------------------------------------------------|------|--------|
| 03/16/20 12:10PM | Pump running as expected. Leak detection on pump is active | | |
| 03/16/20 12:09PM | Pump air valve changed | | |
| 03/16/20 12:09PM | Pump is back online. Diaphragms were changed on the pump | | |
| 03/16/20 12:08PM | Pump is taken offline for maintenance | | |
| 02/27/20 01:21PM | Pump Operational, Pump includes Wilden Safeguard | | |
| 01/29/20 03:08PM | Pump turned on for standard operation | | |

When deleting, a warning window will pop up prior to deletion. To confirm that you wish to delete the Service Record, click “Continue”.



Delete Service

Are you sure you want to delete service ?

Continue
Cancel

Mobile Application

The same features of www.wildensafeguard.com are also available via mobile application for iOS and Android devices. Search for AMI Central on your desired app store. The app gives you the same functionality as the desktop version.

PSG

22069 Van Buren Street Grand Terrace, CA 92313-5651 USA

P: +1 (909) 422-1730 • F: +1 (909) 783-3440

psgdover.com



Where Innovation Flows

PSG® reserves the right to modify the information and illustrations contained in this document without prior notice. This is a non-contractual document. 04-2020